

<http://caraudiotips.blogspot.com/2013/03/hummer-h2-stereo-removal-remote-start.html>

MODEL            YEAR(S)  
H2                2003 -2006

KEY              T-HARNESS      IMMOBILIZER  
N/A              N/A                Has NEW PASSLOCK II Anti-Theft System, Requires Part #XK06 Module

PART	COLOR	LOCATION	DIAGRAM
12 VOLT CONSTANT	RED (+) and RED/WHITE (+)	@ IGNITION SWITCH HARNESS	
STARTER	YELLOW (+)	@ IGNITION SWITCH HARNESS	
IGNITION 1	PINK (+)	@ IGNITION SWITCH HARNESS	
IGNITION 2	WHITE (+)	@ IGNITION SWITCH HARNESS	
ACCESSORY/HEATER BLOWER 1	ORANGE (+)	@ IGNITION SWITCH HARNESS	
ACCESSORY/HEATER BLOWER 2	BROWN (+)	@ IGNITION SWITCH HARNESS	
PARKING LIGHTS ( - )	GRAY/BLACK (-)	@ BCM BROWN Plug, Pin B2, See NOTE *1	
PARKING LIGHTS ( + )	BROWN (+) Left and BROWN/WHITE (+) Right, will require both!	See NOTE *2 in DRIVERS KICK	
PANEL, Harness to Rear of Vehicle, see 26500_H2_DUAL PARKING LIGHT DIAGRAM.pdf			
POWER LOCK	LIGHT BLUE (TYPE B)	@ BCM, PURPLE Plug, Pin B3, See NOTE *1	
POWER UNLOCK	WHITE (TYPE B)	@ BCM, PURPLE Plug, Pin B2, See NOTE *1	
LOCK MOTOR WIRE	GRAY (TYPE C)	@ DRIVERS DOOR Module, in Drivers Door	
DOOR TRIGGER	See NOTE *3    See NOTE *3	17044_H2_(-) NEGATIVE DOOR PIN ISOLATION CIRCUIT.pdf	
DOMELIGHT SUPERVISION	GRAY/BLACK (+)	@ BCM, BLACK Plug, Pin E, See NOTE *1	
HORN	BLACK/YELLOW to BLACK (-)	@ HORN Switch or BCM, GRAY Plug, Pin B9, See NOTE *1	
TACH	WHITE (1-6Volts AC) testing voltage	@ PCM, GREEN Plug, Pin 10, See NOTE *4	
BRAKE	WHITE (+)	@ Switch above BRAKE Pedal	
FACTORY ALARM DISARM	LIGHT GREEN (-)	in DRIVERS DOOR at DOOR Module	

ANTI-THEFT      GM'S New PASSLOCK II System - Requires XK06 Bypass Module

NOTE \*1 The BCM is located behind the HEADLIGHT Switch. The BCM has 6-Plugs, with the PURPLE Plug on the Back of the Module.

NOTE \*2 This vehicle has 2 (+) Positive Parking Light wires, use both, requires 2 extra Relays Part 775 to connect See DIAGRAM

NOTE \*3 the DRIVERS DOOR is a GRAY/BLACK (-) at the DRIVERS DOOR module in the DRIVERS DOOR. The PASSENGER DOOR is a BLACK/WHITE (-) at the PASSENGERS DOOR module in the PASSENGERS DOOR. The DRIVERS REAR DOOR is a LIGHT BLUE/BLACK (-) Pin A3 and the PASSENGERS REAR DOOR is a LIGHT GREEN/BLACK (-) Pin A2, both are located at the BCM, PURPLE plug. When connecting to an ALARM SYSTEM use all 4 wires and DIODE ISOLATE, See DIAGRAM

NOTE \*4 The PCM is located under the Hood of the vehicle, on the Drivers side next to the Battery.

MODEL		YEAR(S)	
H2		2003-2008	
KEY	T-HARNESS	IMMOBILIZER	
N/A	N/A	GM'S PASSLOCK 2 ANTI-THEFT SYSTEM, See NOTE #1	
PART	COLOR	LOCATION	DIAGRAM
12 VOLT CONSTANT	RED (+) and RED/WHITE (+)	@ IGNITION SWITCH HARNESS	
STARTER	YELLOW (+)	@ IGNITION SWITCH HARNESS	
IGNITION 1	PINK (+)	@ IGNITION SWITCH HARNESS	
IGNITION 2	WHITE (+)	@ IGNITION SWITCH HARNESS	
ACCESSORY/HEATER BLOWER 1	ORANGE (+)	@ IGNITION SWITCH HARNESS	
ACCESSORY/HEATER BLOWER 2	BROWN (+)	@ IGNITION SWITCH HARNESS	
PARKING LIGHTS ( - )	GRAY/BLACK (-)	@ BCM. BROWN Plug, Pin B2, See NOTE #2	
PARKING LIGHTS ( + )	BROWN (+) Left and BROWN/WHITE (+) Right, will require both! See NOTE #3	in DRIVERS KICK PANEL, Harness to Rear of Vehicle, See DIAGRAM 26500_H2_DUAL PARKING LIGHT DIAGRAM.pdf	

POWER LOCK	LIGHT BLUE (TYPE B)	@ BCM, PURPLE Plug, Pin B3, See NOTE #2
POWER UNLOCK	WHITE (TYPE B)	@ BCM, PURPLE Plug, Pin B2, See NOTE #2
LOCK MOTOR WIRE	GRAY (5-WIRE TYPE)	@ DRIVERS DOOR Module, in Drivers Door
DOOR TRIGGER	See NOTE #4	17044_H2_(-) NEGATIVE DOOR PIN ISOLATION CIRCUIT.pdf
DOMELIGHT SUPERVISION	GRAY/BLACK (+)	@ BCM, BLACK Plug, Pin E, See NOTE #2
HORN	BLACK/YELLOW to BLACK (-)	@ HORN Switch or BCM, GRAY Plug, Pin B9, See NOTE #2
TACH	WHITE (1-6Volts AC) testing voltage	@ PCM, GREEN Plug, Pin 10, See NOTE #5
BRAKE	WHITE (+)	@ Switch above BRAKE Pedal
FACTORY ALARM DISARM	LIGHT GREEN (-)	in DRIVERS DOOR at DOOR Module

### NOTES

NOTE #1: this vehicle is equipped with GM'S PASSLOCK 2 ANTI-THEFT SYSTEM and requires a bypass module to remote start.

NOTE #2: The BCM is located behind the HEADLIGHT Switch. The BCM has 6-Plugs, with the PURPLE Plug on the Back of the Module.

NOTE #3: This vehicle has 2 (+) Positive Parking Light wires, use both, requires 2 extra Relays Part 775 to connect See DIAGRAM

NOTE #4: the DRIVERS DOOR is a GRAY/BLACK (-) at the DRIVERS DOOR module in the DRIVERS DOOR. The PASSENGER DOOR is a BLACK/WHITE (-) at the PASSENGERS DOOR module in the PASSENGERS DOOR. The DRIVERS REAR DOOR is a LIGHT BLUE/BLACK (-) Pin A3 and the PASSENGERS REAR DOOR is a LIGHT GREEN/BLACK (-) Pin A2, both are located at the BCM, PURPLE plug. When connecting to an ALARM SYSTEM use all 4 wires and DIODE ISOLATE, See DIAGRAM

NOTE #5: The PCM is located under the Hood of the vehicle, on the Driver's side next to the Battery.